

# UNIVERSAL STB REMOTE CONTROL

## Use for Motorola and Cisco STB 6 in 1

ENGLISH

### Introduction


Thank you for using the remote controller. When it is the first time to put in the batteries, please try it first. If it could work well with all of its functions, the product can be used directly without setting it. However, if it could not work well, it should be set with the following methods before remote controlling your STB. The remote controller would not lose its memory when the power is down so that you could replace the battery without resetting it.

### Settings of Remote controller

The remote controller has the following methods of settings, please choose any of them.

A: Inputting code:

1. Turn on STB manually, make it in a normal play state, point the remote controller at the STB, and then find the corresponding STB picture code.
2. Please press the corresponding STB button (only STB1, STB2, STB3, STB4 can be selected), then release it, the corresponding indicator light then input the code STB1.
3. Test whether other function buttons (such as "mute" buttons) could work well. If not, repeat steps 2 until you find the suitable set of code.



Press the "STB1"

then STB1



indicator lights  
then input the code STB1

### Technical parameters

- Remote Controlling Distance: About 10 meters (varies by different types)
- Battery Type: two pieces of AA Batteries

### After-sales Service

If the remote controller has problems or could not be used temporarily, please contact our company as soon as possible. We would make efforts to offer you with best services. But do not disassemble or repair it by yourself. We would not be responsible for remote controllers that have been disassembled without authorization.

To ensure that you could enjoy good after-sales service, please keep the shopping bills or receipts when buying the product.

The Company reserves the final interpretation of this specification. The design and technical parameters could be changed without notice.

## УНИВЕРСАЛЬНЫЙ ПУЛЬТ ДИСТАНЦИОННОГО УПРАВЛЕНИЯ АБОНЕНТСКОГО ПРИЕМНИКА-ДЕКОДЕРА (АПД) Для Motorola и Cisco 6 в 1

РУССКИЙ ЯЗЫК

### Введение

Благодарим за использование данного пульта дистанционного управления. При первом использовании пульта необходимо вставить батареи питания и опробовать пульт в работе. В случае надежной работы всех функций при первом запуске дальнейшая настройка пульта не требуется. В противном случае, до начала дистанционного управления АПД необходимо произвести настройку пульта одним из способов, предложенных ниже. Настройки пульта дистанционного управления сохраняются в памяти при отключении питания, поэтому после замены батарей питания не требуется производить настройку пульта заново.

### Настройка пульта дистанционного управления

Для настройки пульта дистанционного управления следует воспользоваться одним из способов, указанных ниже.

A: Ручной ввод кода:

1. Включить АПД вручную, настроить его на нормальный режим работы, направить пульт дистанционного управления на АПД, затем выбрать на рисунке пульт, который соответствует вашей модели.
2. После того, как на рисунке вы найдёте изображение своего пульта, выберите правильный режим (например STB1). Он указан над изображением пульта. (могут быть выбраны только кнопки STB1, STB2, STB3, STB4), затем отпустить ее, загорится соответствующий индикатор, опробовать работоспособность на ресивере.
3. Убедиться, что кнопки остальных функций (например, кнопки «немоего» режима (mute)) работают должным образом. При неправильной работе каких-либо кнопок повторить инструкции пункта 2 до тех пор, пока не будет найдена подходящая кодовая комбинация.



Нажать STB1 (АПД1)



Загорится индикатор STB1 (АПД1),  
после чего ввести код АПД1

### Технические характеристики

Дальность действия пульта дистанционного управления: около 10 метров (в зависимости от модели)  
Тип батарей питания: 2 батареи типа AA

Компания оставляет за собой право окончательного толкования настоящего технического описания. Внешний вид и технические параметры могут быть изменены без уведомления.

### Compatible Types List-Only use for the STB device

Перечень совместимых моделей - Использовать только для устройства АПД

STB1

STB1

STB2

STB3



CISCO At6400



CISCO 4011708C



MOTOROLA MXv3 VIP2262E



MOTOROLA RCU300T

STB3

STB4

STB4

STB4



VPK



MOTOROLA MXv3 Rc1534849



Beeline RCU01



VPK