

尺寸: 130*180mm

ClickPDU®

RM-L1917

English

Thank you for using our remote controller product. This remote controller can be used directly without setting after inserting batteries. If it could not work well. Please make setting with following methods. This remote controller has a memory function, there is no need to reset it after replacing the batteries.



Inputting code

1. Turn on your TV manually and make it in a normal play state, let the remote control aim to the front of your TV, and then find out the corresponding remote control code of your TV from the "Code Table"
2. Press "POWER" and "INPUT" button together, when the indicator light, then release, enter the corresponding code. The indicator will turn off, setting to be finished.
3. Test the functions (such as Volume button) can work well or not. If not, repeat step 2 until you find the suitable code.

Restore to Factory Mode

Press "POWER" button and "0" button together, then release two buttons, the indicator will flash 3 times, the remote control restores to factory mode.

Technical parameters

Remote Controlling Distance: About 10 meters (varies by different types).
Battery Type: two pieces of AAA Batteries.

Русский

Благодарим за использование данного пульта дистанционного управления. Перед первым использованием данного пульта необходимо вставить батарейки. В случае правильной работы всех функций пульта, дальнейшая настройка пульта не требуется. В противном случае, для корректной работы пульта, необходимо будет произвести настройку. Настройки пульта постоянно хранятся в памяти, поэтому после замены батареек повторную настройку пульта производить не нужно.

Ввод кода

1. Включите телевизор вручную, направьте пульт дистанционного управления на переднюю панель телевизора, а затем найдите соответствующий вашему TV код в "Каталоге пультов".
2. Нажмите кнопку "POWER" и "INPUT" вместе, когда загорится индикатор, затем отпустите, введите соответствующий код. Индикатор погаснет, настройка будет завершена.

3. Проверьте, работают ли функции (например, кнопка громкости). Если нет, повторите шаг 2, пока не найдете подходящий код.

Восстановление заводских настроек

Одновременно нажмите кнопки POWER" и "0", индикатор мигнет три раза. ПДУ вернется к заводским настройкам.

Технические параметры

Расстояние дистанционного управления: около 10 метров (зависит от типа). Тип батареек: две штуки батареек AAA.

ClickPDU® RM-L1917

