

English

Thank you for using the remote controller. When it is the first time to put in the batteries, please try it first. If it could work well with all of its functions, the product can be used directly without setting it. However, if it could not work well, it should be set with the following methods before remote controlling your TV. The remote controller would not lose its memory when the power is down so that you could replace the battery without resetting it.



Settings of Remote controller:

The remote controller has the following methods of settings, please choose any of them.

Inputting code:

- 1, Turn on your TV manually and make it in a normal play state, let the remote control aim to the front of your TV, and then find out the corresponding remote control code of your TV from the "Code Table".
- 2, Press "POWER" and "TV/RADIO" button together, when the indicator light, then release, enter the corresponding code. The indicator will turn off, setting to be finished.
- 3, Test the functions (such as Volume button) can work well or not. If not, repeat step 2 until you find the suitable code.

Automatically searching code:

- 1, Turn on your TV manually and make it in a normal play state, let the remote control aim to the front of your TV.
- 2, Press the "POWER" button, and hold about 6 seconds, the indicator will flash, now the remote control turns to automatic search mode. When volume mark appears on your TV, release the button immediately, the indicator will turn off, setting to be finished.
- 3, Test the functions (such as Volume button) can work well or not. If not, repeat step 2 until you find the suitable code.

Technical parameters:

Remote Controlling Distance: About 10 meters (varies by different types). Battery Type: two pieces of AAA Batteries.

русский

Благодарим за использование данного пульта дистанционного управления. Перед первым использованием данного пульта необходимо вставить батарейки. В случае правильной работы всех функций пульта, дальнейшая настройка пульта не требуется. В противном случае, для корректной работы пульта, необходимо будет произвести настройку, одним из способов, представленных ниже. Настройки пульта постоянно хранятся в памяти, поэтому после замены батареек повторную настройку пульта производить не нужно.



Настройка пульта дистанционного управления:

Настройку пульта можно произвести одним из следующих способов.

Ввод кода:

1. Включите вручную телевизор, направьте пульт на телевизор и найдите соответствующий вашему TV пульт в «Таблице кодов»
2. Нажмите кнопки «POWER» и «TV/RADIO» одновременно, когда индикатор загорится – отпустите обе кнопки. Введите соответствующий код. Индикатор погаснет – настройка завершена.
3. Проверьте функции (например кнопки регулировки звука). Если эти кнопки не работают, то повторите пункт 2, пока не найдёте подходящий код.

Автоматический поиск:


1. Включите телевизор вручную, и направьте пульт на телевизор.
2. Нажмите кнопку «POWER» и удерживайте нажатой, через 6 секунд индикатор заморгает. Теперь пульт находится в режиме авто-поиска. Когда на TV появится шкала регулировки громкости, отпустите кнопку «POWER».
3. Проверьте функции (например кнопки регулировки звука). Если эти кнопки не работают, то повторите пункт 2, пока не найдёте подходящий код.

Технические характеристики


Дальность действия пульта: до 10 метров, в зависимости от модели пульта.
Тип батареек: 2 батарейки AAA.



ERISON_28_32_39_42LEN52(1338) JKT-107 13715 JKT-107 7766 001-JKT-107 18231 JKT-107 18814 JKT-107 19646



JKT-107 HOB1945 KT1045 MTV-2622LW black KT1045 MTV-2622LW white MTV-3224LT2 11189 MTV-3224LT2 13404



MTV-3224LT2 13650 MTV-3224LT2 17312 MTV-3224LT2 17313 MTV-4034LT2 18284 MTV-4034LT2 18299 MTV-4034LT2 18932

