


Prelude

Thank you for using our products! It is our honour to serve you. Read the instructions carefully before using our products for convenience.

About this Remote controller

RM-SAT1111+D multi-function remote controller is the latest product for SAT. It can control almost all SAT made in China or abroad. It has functions of auto searching. With its beautiful body shape and working indicator, it is easy and convenient for you to handle.

Panel Description



B:Auto Search

- 1. Press "SET" and don't release it until the indicator is on;
2. Point the remote to the SAT set;
3. Notices when the mute mark is displayed, press "SET" immediately.

C:Brand Searching

- 1. Turn on SAT manually, make it in a normal play state, point the remote controller at the TV. Find the symbol of your SAT brand, such as STAR SAT with its symbol "1".
2. Press the "corresponding brand symbol" button for about 6 seconds and the work light would continuously flash. When the SAT volume is displayed, release the buttons immediately and the working light would be off, indicating that the setting is done.

D: AUTOMATIC SEARCH FOR TV FUNCTION (4 TV BUTTONS)

- 1. Turn on your tv, test your remote controller, if can use directly, it will no need to set. If can't use, you can set as follow method.
2. Automatic search: hold tv "power" button and don't release, after 6s, the remote controller will start to search automatically, when volume appears on your tv, release the button at once, set to be finished.

Brand table

Table with columns: Key, Brand, 1, 2, 3, 4. Lists brands like STAR SAT, TECH NOSAT, ECHO STAR, TOPFIELD, OPEN BOX, SUPER MAX, STRONG, HVISION, HUMAX.

Specifications

Operable distance: More than 8 meters. Power requirement: Two size AAA batteries.

www.huayu.cc
This company reserves the right to interpretation of the User's Manual. Design and technical parameters may vary without notice.

Installing the batteries

Open the battery lid and pay attention to the +/- marks. Insert two new AAA batteries (not supplied).

Note on batteries

- Do not mix old batteries with new ones or mix different types of batteries together.
If the electrolyte leaks inside the battery compartment, clean it with a piece of cloth and replace the old batteries with new ones.
To prevent the electrolyte from leaking, remove the batteries when you plan not to use the controller for a long period of time.
Replaced with new batteries, previous setup will be saved. It has outage memory function.

A:Input Code

- 1. Please turn on SAT and make the remote face it;
2. Press "SET" and "POWER" simultaneously and don't release them until the indicator is on;
3. After that, please input the 3-digit code.

Russia



Руководство по использованию

Руководство по использованию универсального спутникового пульта ДУ

Резюме продукции

RM-SAT1111 представляет собой универсальный пульт дистанционного управления приспосабливаемый к спутниковому ТВ нового поколения.

Описание панели

C:Способ поиска марки методом точки-точки

- 1. Вручную включите телевизор, когда телевизор находится в состоянии нормального воспроизведения, направьте пульт ДУ на приемник. Найдите символ соответствующей марки вашего телевизора, например STAR SAT.
2. Нажмите, держите кнопку "символа соответствующей марки", через примерно 6 секунд индикатор непрерывно мигает, когда появится символ громкости, немедленно освободите кнопку, индикатор гасит, настройка выполнена.

Сравнительная таблица символов марки

Table with columns: Key, Brand, 1, 2, 3, 4. Lists brands like STAR SAT, TECH NOSAT, ECHO STAR, TOPFIELD, OPEN BOX, SUPER MAX, STRONG, HVISION, HUMAX.

Настройка пульта ДУ:

Настоящий пульт ДУ настроится следующими способами, вы можете выбрать один из них.

A. Способ входного кода:

- 1. Вручную включите приемник, когда приемник находится в состоянии нормального воспроизведения, направьте пульт ДУ на приемник. Найдите трехзначный код соответствующей марки со списка кодов.
2. Нажмите, удержите кнопку "настройки", затем нажмите кнопку "питания", пока индикатор работы загорится, освободите кнопку.
3. В очереди введите первую группу трехзначных кодов. При вводе каждой цифры индикатор мигает один раз, после завершения ввода 3 цифры индикатор работы гасит. Если число групп кодов превышает 1, надо сначала выбрать первую группу кодов.
4. Проверьте другие функциональные кнопки, как кнопку "вспомогательная". Если другие функциональные кнопки не могут нормально работать, повторите операции шаг № 2-3, пока не найдется подходящий код.

B. Способ авто поиска код

- 1. Вручную включите приемник, когда приемник находится в состоянии нормального воспроизведения, направьте пульт ДУ на приемник.
2. Нажмите, удержите кнопку "настройки" более 5 секунд, затем освободите кнопку. При этом индикатор непрерывно мигает, это означает, что программа авто поиска кода уже запускается.
3. При появлении символа "громкости" немедленно нажмите кнопку "настройки", индикатор "настройки" гасит, при этом настройка завершается.
4. Проверьте другие функциональные кнопки, как кнопку "вспомогательная". Если другие функциональные кнопки не могут нормально работать, повторите операции шаг № 2-3, пока не найдется подходящий код.

A. Ввод номера кода

- 1. Вручную включите телевизор, когда телевизор находится в состоянии нормального воспроизведения, направьте пульт ДУ на приемник. Найдите символ соответствующей марки вашего телевизора, например STAR SAT.
2. Нажмите, держите кнопку "символа соответствующей марки", через примерно 6 секунд индикатор непрерывно мигает, когда появится символ громкости, немедленно освободите кнопку, индикатор гасит, настройка выполнена.

Arabia

البحث التلقائي B

- الريموت متوجه على الريسفر المفتوح
الضغط الزر SET حتى يشغل اللبثيات
الضغط الزر SET عندما اظهر الزر MUTE وتم الاعداد

C: البحث الماركات

الريموت متوجه على الريسفر المفتوح
تجد قائمة الاسماء مثلا: STARSAT مطابقه رقم 1
الضغط الزر المطابق الماركات ويشغل اللبثيات بعد ست ثانية حتى ترا علامة الصوت في التلفاز
ثم ترك ضغط الزر واطفاء اللبثيات تم الاعداد

Table with columns: Key, Brand, 1, 2, 3, 4. Lists brands like STAR SAT, TECH NOSAT, ECHO STAR, TOPFIELD, OPEN BOX, SUPER MAX, STRONG, HVISION, HUMAX.

Table with columns: Key, Brand, 1, 2, 3, 4. Lists brands like STAR SAT, TECH NOSAT, ECHO STAR, TOPFIELD, OPEN BOX, SUPER MAX, STRONG, HVISION, HUMAX.

Table with columns: Key, Brand, 1, 2, 3, 4. Lists brands like STAR SAT, TECH NOSAT, ECHO STAR, TOPFIELD, OPEN BOX, SUPER MAX, STRONG, HVISION, HUMAX.

Table with columns: Key, Brand, 1, 2, 3, 4. Lists brands like STAR SAT, TECH NOSAT, ECHO STAR, TOPFIELD, OPEN BOX, SUPER MAX, STRONG, HVISION, HUMAX.

Table with columns: Key, Brand, 1, 2, 3, 4. Lists brands like STAR SAT, TECH NOSAT, ECHO STAR, TOPFIELD, OPEN BOX, SUPER MAX, STRONG, HVISION, HUMAX.

Table with columns: Key, Brand, 1, 2, 3, 4. Lists brands like STAR SAT, TECH NOSAT, ECHO STAR, TOPFIELD, OPEN BOX, SUPER MAX, STRONG, HVISION, HUMAX.

Table with columns: Key, Brand, 1, 2, 3, 4. Lists brands like STAR SAT, TECH NOSAT, ECHO STAR, TOPFIELD, OPEN BOX, SUPER MAX, STRONG, HVISION, HUMAX.

Table with columns: Key, Brand, 1, 2, 3, 4. Lists brands like STAR SAT, TECH NOSAT, ECHO STAR, TOPFIELD, OPEN BOX, SUPER MAX, STRONG, HVISION, HUMAX.

Table with columns: Key, Brand, 1, 2, 3, 4. Lists brands like STAR SAT, TECH NOSAT, ECHO STAR, TOPFIELD, OPEN BOX, SUPER MAX, STRONG, HVISION, HUMAX.

Table with columns: Key, Brand, 1, 2, 3, 4. Lists brands like STAR SAT, TECH NOSAT, ECHO STAR, TOPFIELD, OPEN BOX, SUPER MAX, STRONG, HVISION, HUMAX.

Table with columns: Key, Brand, 1, 2, 3, 4. Lists brands like STAR SAT, TECH NOSAT, ECHO STAR, TOPFIELD, OPEN BOX, SUPER MAX, STRONG, HVISION, HUMAX.

Table with columns: Key, Brand, 1, 2, 3, 4. Lists brands like STAR SAT, TECH NOSAT, ECHO STAR, TOPFIELD, OPEN BOX, SUPER MAX, STRONG, HVISION, HUMAX.

Table with columns: Key, Brand, 1, 2, 3, 4. Lists brands like STAR SAT, TECH NOSAT, ECHO STAR, TOPFIELD, OPEN BOX, SUPER MAX, STRONG, HVISION, HUMAX.

Table with columns: Key, Brand, 1, 2, 3, 4. Lists brands like STAR SAT, TECH NOSAT, ECHO STAR, TOPFIELD, OPEN BOX, SUPER MAX, STRONG, HVISION, HUMAX.

Table with columns: Key, Brand, 1, 2, 3, 4. Lists brands like STAR SAT, TECH NOSAT, ECHO STAR, TOPFIELD, OPEN BOX, SUPER MAX, STRONG, HVISION, HUMAX.

Table with columns: CODE, CN, MODEL. Lists various satellite receiver models and their codes.

Table with columns: CODE, CN, MODEL. Lists various satellite receiver models and their codes.

Table with columns: CODE, CN, MODEL. Lists various satellite receiver models and their codes.

Table with columns: CODE, CN, MODEL. Lists various satellite receiver models and their codes.

Table with columns: CODE, CN, MODEL. Lists various satellite receiver models and their codes.

Table with columns: CODE, CN, MODEL. Lists various satellite receiver models and their codes.

Table with columns: CODE, CN, MODEL. Lists various satellite receiver models and their codes.