

HUAYU[®] RM-L1365 Plus LCD/LED TV REMOTE CONTROLLER


Русский

Поиск нужной марки телевизора с помощью ввода кода вручную

1. Включите телевизор и в перечне кодов найдите тот, который соответствует марке Вашего телевизора.



2. Одновременно нажимайте кнопки "POWER" и "SOURCE", пока не загорится индикаторная лампочка.



3. Введите три первых цифры кода, соответствующего модели телевизора. После ввода кода индикатор перестанет гореть, установка завершена



4. Проверьте работу кнопок на ПДУ. При наличии проблем повторно выполните процедуру настройки, начиная с шага 2.



EN-33933HS EN-33927A EN-33922A EN2BK27H ERF3A90 EN3I39H EN2A27 EN-22652A EN2H27HS EN-31906D ERF2M60B EN2B27 ERF3S69H



EN2BZ27B EN-21662B EN-31603B EN2N30H EN3A70 EN3AB39H ERF3169H ERF3Q69 FH210705000050Y1 RC1736 EN2J30H EN3AG39H ER-33912B



ER-31607R ER-22655HS ER-22642R ER-22641R EN-31907 EN-32963HS EN-31603A EN-31603A EN-21662 ER-32961HS ER-22654 ER-22601A EN2H27B



ER-33911BN EN-33926A CN3B16 CN3B12 CN3A26

Thank you for using our company remote controller products. When it is the first time to put in the batteries, please try it first. If it could work well with all of its functions, the product can be used directly without setup. If it could not work well, it should be set with the following methods before controlling your TV. This remote controller would not lose its memory when you change batteries, no need to reset.



Inputting code:
1. Turn on your TV set, let your TV set be in the normal state play, and aim the remote controller in the front of the TV. Find the three digits code from the code list.



2. Press "POWER" button, then press "SOURCE" button, till the indicator lamp lights, then release the buttons, the remote controller will be in the state of inputting code.



3. Enter the first set of three-digit code in order. When you input each digit, the indicator lamp will flash one time, when you enter all of the three digits, the indicator lamp will turn off., setting to be finished. If the code is more than one set, please use first one at first.



4. Test other function buttons can work well or not, such as "MUTE". If not, repeat steps 2 to 3, until you find the suitable code.

