


В. Ручной ввод кода

1.

Вручную подключитесь к кондиционеру, отыщите тип кондиционера в «таблице кода», а также отыщите первый код, например, Haier
2.

Удерживайте кнопку «SET1» (в течение 3 секунд) пока код кондиционера не мигнет, нажмите кнопку регулировки температуры «▲» или «▼» пока соответствующий код не появится на экране. После установки необходимого кода произойдет запуск кондиционера.



| Торговая марка | Код     |
|----------------|---------|
| Haier          | 020~037 |



3.

3. Нажмите кнопку «SET1» и выбранный код кондиционера перестанет мигать.
4.

Проверьте правильно ли была произведена настройка кнопки удаленного управления. Если да — настройка завершена. Если нет, повторите шаги 2-3.




Автоматический поиск

1.


Вручную подключитесь к кондиционеру, направьте пульт дистанционного управления на приемник кондиционера.
2.

Удерживайте кнопку «SET1» (в течение примерно 6 секунд) пока код типа кондиционера отображаемый на экране не изменится, что будет являться показателем того, что вы вошли в меню быстрого поиска статуса кондиционера. Отпустите кнопку «SET» для прекращения поиска, пока не произойдет автоматический запуск кондиционера.



3.

Проверьте работу кнопок дистанционного управления (за исключением кнопок регулировки температуры, а также кнопок установки времени). Если они работают правильно, значит был установлен верный код. Если нет — повторите шаг 2.



Функция установки времени

Удерживайте кнопку «CLOCK» (в течении 3 секунд) для входа в меню настроек времени, после чего часы должны начать мигать. Используйте кнопки регулировки температуры «▲» или «▼» для установки правильного времени, а также нажмите кнопку установки времени для установки текущего значения, еще раз нажмите кнопку установки времени для выхода из меню.

Функция отложенного ВКЛЮЧЕНИЯ/ВЫКЛЮЧЕНИЯ

Для регулировки функции дистанционного управления, нажмите кнопки «TIME ON» или «TIME OFF», после чего на кондиционере загорятся индикаторы времени, демонстрирующие, что кондиционер перешел в режим таймерного управления. Функция отложенного включения кондиционеров некоторых марок доступна только при отключенном питании кондиционера.

Причины нагрева:

- Данный пульт дистанционного управления работает, только при рабочем приемнике кондиционера
- Если пульт дистанционного предполагается использовать в течение короткого промежутка времени, рекомендуем извлечь элементы питания.
- Причиной может также послужить ошибки в программном обеспечении пульта дистанционного управления, если он используется некорректно, в этом случае, извлеките элемент питания, а затем вставьте его обратно спустя 30 минут, после чего пульт дистанционного управления должен восстановить свою функциональность.

Applicable Brand and Code List Соответствующие торговые марки и список кодов

| Brand           | Торговая марка | Code                                                            | Код |
|-----------------|----------------|-----------------------------------------------------------------|-----|
| GREE            |                | 000~019,247,460,887,996                                         |     |
| MIDEA           |                | 038~048,313,400,435,814                                         |     |
| Haier           |                | 020~037,056,222,227,243,665,989                                 |     |
| SAMSUNG         |                | 272,315,338,646~665,937                                         |     |
| LG              |                | 636~645                                                         |     |
| Panasonic       |                | 334,341,456,690~705,974~976                                     |     |
| AUX             |                | 007,167~184,499                                                 |     |
| CARRIER         |                | 706~718,845,922                                                 |     |
| CHANGHONG       |                | 045,049~071,243,256,402                                         |     |
| CHIGAO          |                | 072~089,346,415                                                 |     |
| CHUNLAN         |                | 159~166,316                                                     |     |
| DAIKIN          |                | 318,406,437,751~774,850                                         |     |
| ELECTROLUX      |                | 001,044,045,137,275,298,317,339,339,391,497~504,848,860,920,963 |     |
| FUJITSU ZHENBAO |                | 403,719~736                                                     |     |
| Galanx          |                | 134~142,282,393,964                                             |     |
| HISENSE         |                | 179,208~217,260,274,474                                         |     |
| HITACHI         |                | 249,421,497, 674~689,939                                        |     |
| KELONG          |                | 109~118                                                         |     |
| MEILING         |                | 394~397,840~843                                                 |     |
| mitsubishi      |                | 074,159,392,454,475,499,589~635,777,815,859,874,947,948,988     |     |
| MITSUKA         |                | 905                                                             |     |
| SANYO           |                | 297,332,453,537~588                                             |     |
| SHARP           |                | 319,477,744~750,944                                             |     |
| SHINCO          |                | 185~188,331,390,429                                             |     |
| SKYWORTH        |                | 270                                                             |     |
| TCL             |                | 119~133,248,347,446                                             |     |
| TOSHIBA         |                | 255,271,666~673,967                                             |     |
| WHIRLPOOL       |                | 174,787~791,978                                                 |     |
| YORK            |                | 417,792~793,962~963                                             |     |

| Brand           | Торговая марка | Code            | Код |
|-----------------|----------------|-----------------|-----|
| ACSOM           |                | 881             |     |
| AIDELONG        |                | 242,244~246     |     |
| AIDELONG        |                | 925             |     |
| AITE            |                | 249~253         |     |
| AKIRA           |                | 804             |     |
| ALPIN           |                | 883~886         |     |
| AMICO           |                | 882             |     |
| AMICO           |                | 887             |     |
| AOKE            |                | 257~259         |     |
| AOLI            |                | 254~255         |     |
| APTON           |                | 888             |     |
| AUCMA           |                | 189~207,863,956 |     |
| BAIXUE          |                | 261             |     |
| BANSHEN         |                | 870             |     |
| BANTIAN         |                | 958             |     |
| BEIJINGJINGDIAN |                | 264~265         |     |
| BIG-THUMB       |                | 305             |     |
| BOERKA          |                | 889             |     |
| BOERKA/LITTLESW |                | 266~269,357     |     |
| BORLER          |                | 273             |     |
| BOSHI           |                | 278~280         |     |
| BOSHIGAO        |                | 276~277         |     |
| BROTHER         |                | 936             |     |
| CAIXING         |                | 281~283         |     |
| CHANGFENG       |                | 845             |     |
| CHANGFU         |                | 829~831         |     |
| CHANGLING       |                | 284~295         |     |
| CHENGDUAN       |                | 875             |     |
| CHUANGHUA       |                | 296,298~302     |     |
| CHUANYAN        |                | 928             |     |

| Brand      | Торговая марка | Code        | Код |
|------------|----------------|-------------|-----|
| COLROLLA   |                | 890         |     |
| CONROWA    |                | 320~330     |     |
| CONSUL     |                | 891         |     |
| CORONA     |                | 775~786     |     |
| DAEWOO     |                | 306~311     |     |
| DAJINXING  |                | 303~304     |     |
| DAKE       |                | 929         |     |
| DAOTIAN    |                | 816~817     |     |
| DELONGHI   |                | 892         |     |
| DOGNXIA    |                | 312         |     |
| DONGXIA    |                | 312~316     |     |
| DONGXINBAO |                | 229         |     |
| DUNAN      |                | 317         |     |
| ELCO       |                | 893         |     |
| ELECTER    |                | 894~899     |     |
| FEDDERS    |                | 900         |     |
| FEDDERS    |                | 949         |     |
| FEIEDRICH  |                | 901         |     |
| FEIGE      |                | 945~946     |     |
| FEILU      |                | 218~221     |     |
| FERROLIT   |                | 902         |     |
| FIRST      |                | 903         |     |
| FRESTECH   |                | 230~239     |     |
| GEER       |                | 333~334     |     |
| Goldstar   |                | 262~263     |     |
| GUANGDA    |                | 337,339~341 |     |
| GUQIAO     |                | 335~336     |     |
| HELTON     |                | 904         |     |
| HEMILTON   |                | 937         |     |
| HICON      |                | 398         |     |

| Brand          | Торговая марка | Code                | Код |
|----------------|----------------|---------------------|-----|
| HUABAO         |                | 090~108,954         |     |
| HUAGAO         |                | 342                 |     |
| HUAKE          |                | 343                 |     |
| HUALIN         |                | 143~158,314,459,957 |     |
| HUAMEI         |                | 344~346             |     |
| HUANGYE        |                | 876~877             |     |
| HUNDAI/DAEWOO  |                | 796~797             |     |
| INYCIN         |                | 505~515             |     |
| JIALE          |                | 354                 |     |
| JIANGNAN       |                | 355                 |     |
| JINBEIJING     |                | 359                 |     |
| JINDA          |                | 531~533             |     |
| JINLI          |                | 961                 |     |
| JINSONG        |                | 360~363             |     |
| JMSTAR         |                | 356,358             |     |
| JOHNSO         |                | 873~874             |     |
| KANGBAIEN      |                | 868                 |     |
| KANGLI         |                | 371~374             |     |
| KLIMATAIR      |                | 805~810             |     |
| KONKA          |                | 364~367             |     |
| KRIS           |                | 811                 |     |
| LIANGYU        |                | 794                 |     |
| LIKEAIR        |                | 390~393             |     |
| Likeair        |                | 391~392             |     |
| LONGHE         |                | 930                 |     |
| LUOLANSIBAO    |                | 869                 |     |
| MCQUAY         |                | 798~803             |     |
| MINGXING/BOYIN |                | 240~241             |     |
| MINGYI         |                | 942~943             |     |
| NIKKO          |                | 812~813             |     |

| Brand       | Торговая марка | Code        | Код |
|-------------|----------------|-------------|-----|
| NISO        |                | 848~849     |     |
| NISO        |                | 861         |     |
| NORCA       |                | 906         |     |
| OLYMPUS     |                | 926~927     |     |
| OPAL        |                | 907         |     |
| PANDA       |                | 478~483     |     |
| PEREG       |                | 908         |     |
| PILOT       |                | 909         |     |
| PUYI        |                | 931         |     |
| QIONGSHENG  |                | 872         |     |
| QIXING      |                | 399         |     |
| RAYBO       |                | 375~386     |     |
| RHOSS       |                | 910         |     |
| RICAI       |                | 401         |     |
| RIJIANG     |                | 404~406     |     |
| ROWA        |                | 387~389,953 |     |
| SACON       |                | 420,422     |     |
| SAJIUDIANJI |                | 938         |     |
| SAJIUDIANJI |                | 950~951     |     |
| SAJO DENK   |                | 940~941     |     |
| SAJO DENKI  |                | 948~949     |     |
| SANYE       |                | 932         |     |
| SANZUAN     |                | 844         |     |
| SAPORO      |                | 911         |     |
| SAST        |                | 461~465     |     |
| SENSOR      |                | 912         |     |
| SERENE      |                | 880         |     |
| SHAMEI      |                | 850         |     |
| SHANGLING   |                | 408~413     |     |
| SHANGXING   |                | 407         |     |

| Brand           | Торговая марка | Code            | Код |
|-----------------|----------------|-----------------|-----|
| SHENBAO         |                | 414,416         |     |
| SHENGBAO        |                | 737~743         |     |
| SHENGFENG       |                | 418~419         |     |
| SHENGFENGFEILU  |                | 851             |     |
| SHINING         |                | 423~424         |     |
| SHUANGLU        |                | 425~428         |     |
| SOGO            |                | 846             |     |
| SONGLINXIA      |                | 933             |     |
| SONGXING        |                | 429             |     |
| SOVA            |                | 430~431,954     |     |
| SOWA            |                | 913~914         |     |
| SOYEA           |                | 432             |     |
| SPEED           |                | 915             |     |
| SRTC            |                | 879             |     |
| STARIGHT-AIRCON |                | 916             |     |
| SUNBURG         |                | 866             |     |
| TADIAIR         |                | 917~921,923~924 |     |
| TAIYA           |                | 934             |     |
| TEAC            |                | 839             |     |
| TIANJINKONGTIAO |                | 433~434         |     |
| TIANYUAN        |                | 436~440         |     |
| TOBO            |                | 222~228         |     |
| TONGLI          |                | 852~853         |     |
| TOYO            |                | 348~353         |     |
| TOYO(TECO)      |                | 818~828         |     |
| TRANE           |                | 862~865         |     |
| UNI-AIR         |                | 368~370         |     |
| UTTLEDUCK       |                | 466~473         |     |
| WANBAO          |                | 441~445,972     |     |
| WANGZI          |                | 935             |     |

| Brand        | Торговая марка | Code            | Код |
|--------------|----------------|-----------------|-----|
| WEILI        |                | 447~452         |     |
| WUFENG       |                | 455~456         |     |
| XILENG       |                | 457~460         |     |
| XINGE        |                | 960             |     |
| XINGHE       |                | 476~477         |     |
| XINGXING     |                | 952             |     |
| XINLE        |                | 855~858         |     |
| XINLING      |                | 859             |     |
| YAIR         |                | 484~491,399,854 |     |
| YAOMA        |                | 492~496,955     |     |
| YIDONG       |                | 878             |     |
| YOUNIAIER    |                | 871             |     |
| YUETU        |                | 965             |     |
| YUTU         |                | 516~530         |     |
| ZHONGYI      |                | 534~536         |     |
| ZUODAN       |                | 860             |     |
| VESTEL       |                | 959             |     |
| BLUE STAR    |                | 867             |     |
| VIDEOCON     |                | 968             |     |
| VOLTAS       |                | 847,966,970~971 |     |
| Other Brands |                | 977~999         |     |

This company reserves the right to interpretation of the User Manual. Design and technical parameters may vary without notice.  
Компания оставляет за собой право толкования Руководства пользователя. Дизайн и технические параметры могут изменяться без уведомления.

## User's instructong for all-purpose air conditioner remote controller

K-1038E+L type universal air conditioner remote control can remotely control most brands and models of air conditioners with digital automatic code searching function with low power consumption, complete function, far sending distance, easy setting, simple operation, original appearance, comfortable handle and convenient use, it applies big LCD display with clear settings, built-in clock and timing ON/OFF function also make operation more convenient.

The diagram shows a white universal A/C remote control with a black display screen and various buttons. The labels and their corresponding functions are as follows:

- Signal Sending Display:** Points to the top left of the display screen.
- Fan Display:** Points to the fan icon on the display screen.
- Model Code Display:** Points to the numbers '08' on the display screen.
- Run Mode Display:** Points to the top right of the display screen.
- Temperature Display:** Points to the temperature value '28' on the display screen.
- Temperature "-" Key:** Points to the left arrow button labeled 'TEMP'.
- Temperature "+" Key:** Points to the right arrow button labeled 'TEMP'.
- Mode Key:** Points to the 'MODE' button.
- Manually Blowing Direction Control Key:** Points to the 'DIR' button.
- Power Key:** Points to the 'POWER' button.
- Automatic Blowing Direction Control Key:** Points to the 'DIR' button.
- Fan Key:** Points to the 'FAN' button.
- Clock Function Key:** Points to the 'CLOCK' button.
- Timing ON Key:** Points to the 'ON' button.
- Timing OFF Key:** Points to the 'OFF' button.
- Backlight LED Key:** Points to the 'LED' button.

At the bottom of the remote, the text reads: **ClickPDU®**, **K-1038E+L**, and **Universal A/C Remote**.

**Fast Cool/Heat Key**

- Press "Fast Cool" key to automatically set the machine as refrigerating mode, 21 °C, middle wind, automatic blowing direction;
- Press "Fast Heat" key to automatically set the machine as heating mode, 27 °C, middle wind, automatic blowing direction.
- Press "LED" key to OPEN LED LIGHT.
- Press "SET1" key or "SET2" to you can controlling two air-conditioning.

1.Remove the battery cover of the remote control, install two new 7#batteries;



The diagram shows a top-down view of the remote control. A small lever on the left side of the battery compartment is being pushed upwards, as indicated by a curved arrow. This action is designed to lift the battery cover, which is shown in a partially open position.


2.Install the battery cover. The time will appear in the left corner of LCD display.



The diagram shows a top-down view of the remote control. The battery cover is being placed back onto the battery compartment. A straight arrow points downwards towards the cover, indicating the direction of installation.

This remote controller has 3 setting modes that are marked as A,B,C and D. Please select one mode for operation.


1. Manually plug-in the air conditioner, aim the remote control at the receiving window of the air conditioner.
2. Press the code key that corresponds to your brand and hold until the air conditioner is started by giving out a sound signal. Release the key and the setting is completed.




| ON/OFF            | TEMP ▲         | TEMP ▼            | FAN                |
|-------------------|----------------|-------------------|--------------------|
| GREEN/haier       | MIDEACHANGHONG | CHIGO/AUX         | CHUNLAN/AUCMA      |
| MODE              | M.SWING        | A.SWING           | TIME ON            |
| HISENSE/KELONG    | HUABAO/OTHER   | TCL/HUALING       | SHARP/MITSUBISHI   |
| TIME OFF          | FAST COOL      | FAST HEAT         | CLOCK              |
| TOSHIBA/SANYO/NEC | SAMSUNG/LG     | Panasonic/HITACHI | FUJITSU/Electrolux |

1. Manually plug-in the air conditioner, find the type of the air conditioner in the "code table", and find the first code, for example: Haier
2. Hold "SET1" button (for about 3 seconds) until the conditioner type code flickers in the window, press temperature "▲" or "▼" buttons until the desired code flickers in the window. When the code is right, the air conditioner will start.


| Brand | Code    |
|-------|---------|
| Haier | 020~037 |




|                                                                                  |                                                                                                                          |
|----------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------|
| 3.                                                                               | 4.                                                                                                                       |
| Press "SET1" button and the selected conditioner type code will stop flickering. | Test whether the remote control button has been effectively set. if yes, setting completes. and if no, repeat steps 2-3. |



1. Manually plug-in the air conditioner, aim the remote control at the receiving window of the air conditioner.
2. Hold "SET1" button (for about 6 seconds) until the conditioner type code changes in the window, indicating you have entered the high-speed conditioner type search status. release "SET1" button to stop searching until the air conditioner automatically start.



3. Test whether the functions of remote control buttons (excluding temperature and buttons, timed ON/OFF buttons, and "SET1" button) are correct. if yes, the code is effectively set. and if no, repeat steps 2.



Press clock button (for 3 seconds) to enter the clock setting status, and the clock will flicker. Use the temperature "▲" or "▼" buttons to adjust the current time, and press clock button again to exit setting.

To configure the function of the original remote control, press "TIME ON" or "TIME OFF" buttons, and the air conditioner timer lights will go on, indicating the air conditioner has entered the timed status.

※ The timed on function of some of the air conditioner types is only valid only in the power off status.

😊 Warm tips:

- This remote control is effective if the air conditioner receiver works normally.
- If this remote control is intended to be not in use for a long time, please remove the batteries.
- It may possibly caused internal program disorder if this remote control is not operated correctly, in case of that, please take out the battery, and install the batteries 30 minutes later, then the remote control may recover normal.

Руководство пользователя для многофункционального пульта  
дистанционного управления кондиционером

К-1038E+L является универсальным пультом дистанционного управления, позволяющего осуществлять дистанционное управление кондиционерами большинства торговых марок и моделей посредством функции цифрового автоматического поиска кода. Данное устройство обладает низким уровнем потребления энергии, полной функциональностью, возможностью передавать сигнал на большое расстояние, простотой настройки, легкостью управления, оригинальным дизайном, превосходной эргономикой. Кроме того, устройство оснащено LCD-дисплеем с простыми для понимания настройками, встроенными часами и возможностью установки отложенного ВКЛЮЧЕНИЯ/ВЫКЛЮЧЕНИЯ, что делает использование настоящего устройства еще более удобным.

Экран подачи сигнала

АВТОРЕГУЛИРОВАНИЕ:

Экран ручного регулирования воздушного

Экран автоматического регулирования воздушного

Кнопка определения

Направления воздушного потока

Вкл./Выкл.

Кнопка меню часов

Установка времени

Кнопка настройки

1000 IN 1

TEMP

TEMP -

TEMP +

Автоматическая регулировка направления воздушных потоков

Кнопка регулирования силы воздушного потока

Установка времени выключе


LED Key

ClickPDU®


K-10380-L

Universal AC Remote

Снимите крышку отсека элементов питания пульта дистанционного управления, установите две новые батареи № 7;



2. Установите крышку отсека элементов питания. Время отобразится в левом углу LCD-дисплея.





Данный пульт дистанционного управления обладает 3 режимами настроек, помеченными как А, В, С. Для начала работы выберите один из них.

А. Широкий и точный, а также быстрый поиск точка-точка

1.  
Вручную подключитесь к кондиционеру, направьте пульт дистанционного управления на приемник кондиционера.

2. Введите код соответствующий торговой марке вашего устройства и удерживайте кнопку до момента запуска кондиционера, который издаст звуковой сигнал. Отпустите кнопку, после чего настройка будет завершена



| ON/OFF            | TEMP ▲          | TEMP ▼            | FAN                |
|-------------------|-----------------|-------------------|--------------------|
| GREEN/haier       | MIDEA/CHANGHONG | CHIGO/AUX         | CHUNLAN/AUCMA      |
| MODE              | M.SWING         | A.SWING           | TIME ON            |
| HISENSE/KELONG    | HUABAO/OTHER    | TCL/HUALING       | SHARP/MITSUBISHI   |
| TIME OFF          | FAST COOL       | FAST HEAT         | CLOCK              |
| TOSHIBA/SANYO/NEC | SAMSUNG/LG      | Panasonic/HITACHI | FUJITSU/Electrolux |